



NOTE:  
 CLEAN SURFACE AND APPLY ASPHALT EMULSION TACK COAT PRIOR TO PLACING HOT MIX ASPHALT SURFACE OVERLAY.



TOWN OF FRAMINGHAM  
 DEPARTMENT OF PUBLIC WORKS

PAVEMENT TRANSITION

DATE:  
 FEB. 2010

REV:  
 0

DETAIL NO.

R-5.1.4