



NOTES:

1. INSTALL SADDLE FIRST, THEN CORE HOLE.
2. INSERT-A- TEE SERVICE CONNECTORS MAY BE ALLOWED UPON SPECIFIC DPW APPROVAL.

NOT TO SCALE



TOWN OF FRAMINGHAM
DEPARTMENT OF PUBLIC WORKS

**SERVICE CONNECTION
(SADDLE)**

DATE:
MAR. 2012

REV:
1

DETAIL NO.

S-3.1.1